



*Waterslide
Decals*



WATERSLIDE DECALS Collection

DEW · 29,7x41cm, printed on Decalcomania paper.

TRS · 29,7x42cm, printed on Decalcomania paper.



ENGLISH:

Waterslide decals can be transferred to any smooth surface for decorative purposes such as glass, metal, ceramic, candles, soap bars, picture frames, etc. This technique allows even those who are not very skilled at the decoupage technique to create a beautiful decorative effect.

The decals can be used also on those supports subject to wear such as plates, cups, ashtrays, as well as glass and pottery objects suitable for high-temperature cooking at home.



DEW 01 printed on Decalcomania paper

To grant a long-lasting life to your objects baking is recommended as per following instructions:

- 1.** Cut out the subject to be transferred, taking care not to cut the image.
- 2.** Soak the clipped image into cold water for one minute, slide it carefully on the object to be decorated, and use a microfibre cloth to press out gently the water and air bubbles.
- 3.** Pre-heat the oven to 180 ° and bake the object for one hour.
- 4.** Turn off the oven and let it cool inside before taking it out. It is recommended to wash it by hand and not in the dishwasher.

*To get a flawless result on porous surfaces such as paper, wood, and similar, apply first a layer of primer or color and last a finishing paint layer.

Collezione DECALCOMANIA A SCIVOLO

DEW · 29,7x41cm, stampate su carta Decalcomania.

TRS · 29,7x42cm, stampate su carta Decalcomania.

ITALIANO:

La decalcomania a scivolo, può essere applicata su qualsiasi superficie liscia per scopi decorativi come vetro, metallo, ceramica, candele, saponette, cornici ecc. e permette anche a chi non è portato alla tecnica del *découpage* di creare lo stesso effetto decorativo.

È possibile estendere l'uso della decalcomania anche su utensili quali ad esempio piatti, tazze, posacenere, bicchieri e oggetti in vetro e ceramica che si possono utilizzare per cucinare nel forno di casa.




TRS 06 printed on Decalcomania paper


Per un uso permanente consigliamo la cottura in forno come da istruzioni:

1. Ritagliare il soggetto da trasferire facendo attenzione a non ritagliare dove è situata l'immagine.
2. Mettere il ritaglio nell'acqua fredda per un minuto, far scivolare lentamente l'immagine sull'oggetto da decorare. Tamponare delicatamente l'acqua in eccesso.
3. Prima far scaldare il forno a 180°, successivamente far cuocere il manufatto per un'ora.
4. Una volta cotto, spegnere il forno e lasciare l'oggetto raffreddare all'interno. Si consiglia di lavare a mano e non in lavastoviglie.


*L'uso su superfici quali cartone, carta, legno e superfici porose, richiede la stesura di un primer o colore prima della sua applicazione, con relativa vernice di finitura per un risultato impeccabile.



TRS 01 printed on Decalcomania paper




TRS 02 printed on Decalcomania paper




TRS 03 printed on Decalcomania paper





TRS 04 printed on Decalcomania paper



TRS 05 printed on Decalcomania paper



TRS 07 printed on Decalcomania paper





Calambour s.r.l.
Corso Lodi, 74 - Milano - Italy
+39 02552314 41
www.calambour.com

Follow us on:

